

# Command Set Overview

## Reference Key:

# - is the IO Bit Number

m - is the mask value of which bits are affected

W - defines it as a word (16 bits)

expression - an expression must contain no more than a total maximum of 32 operators, values, and parenthesis.

value - a number, variable or math expression with one operand

constant - means a fixed integer

gen# Trajectory generator number: 1 or 2

i - Interrupt number , valid values are from 0 to 7

## Communication Commands:

|                         |  |
|-------------------------|--|
| <b>ADDR=expression</b>  | Set motor's serial communications address. Applies for both RS232 and RS485              |
| <b>BAUD(x)=y</b>        | This allows for COM0 or COM1 to be changed, x is the channel (0 or 1) and y is baud rate |
| <b>CADDR=expression</b> | Set CAN address, can be different from serial address, default is 63                     |
| <b>CBAUD=expression</b> | Set CAN baud rate, default is 125000   |
| <b>CCHN(RS2,0)</b>      | Close communication channel command  |
| <b>ECHO</b>             | Must be used to insure all data received in one motor will be echoed to next motor       |
| <b>ECHO_OFF</b>         | Default, turn communication's echo off   |
| <b>GETCHR</b>           | Get the next character from channel 0  |
| <b>GETCHR1</b>          | Get the next character from channel 1  |
| <b>LEN</b>              | Number of characters in channel 0 buffer   |
| <b>LEN1</b>             | Number of characters in channel 1 buffer   |
| <b>RCADDR</b>           | Reports CAN address  |
| <b>RCBAUD</b>           | Reports CAN baud rate  |
| <b>RCHN(0)</b>          | Report channel 0 error bits  |
| <b>RCHN(1)</b>          | Report channel 1 error bits  |
| <b>SILENT</b>           | Ignore print commands to channel 0 from user program                                     |
| <b>SILENT1</b>          | Ignore print commands to channel 1 from user program                                     |
| <b>SLEEP</b>            | Ignore commands for channel 0 except the WAKE command                                    |
| <b>SLEEP1</b>           | Ignore commands for channel 1 except the WAKE command                                    |
| <b>STDOUT=0</b>         | Sets internal report commands to RS232 (default)   |
| <b>STDOUT=1</b>         | Sets internal report commands to RS485   |
| <b>TALK</b>             | Enable prints for channel 0 from user program  |
| <b>TALK1</b>            | Enable prints for channel 1 from user program  |
| <b>WAKE</b>             | Wake for channel 0   |
| <b>WAKE1</b>            | Wake for channel 1   |

## Program Flow Commands:

|                        |   |
|------------------------|---|
| <b>CASE expression</b> | Switch case statement   |
| <b>C constant</b>      | Subroutine label, e.g. C10 for subroutine 10, must have a RETURN for each C label |
| <b>DEFAULT</b>         | Default action for switch case statement  |
| <b>DITR(i)</b>         | Individual interrupt disable  |

|   |  |
|---|--|
| <b>EITR(i)</b>                              | Individual interrupt enable  |
| <b>ELSEIF expression</b>                    | Used for IF statements to test another condition, if expression is true, then execute code               |
| <b>END</b>                                  | End program execution  |
| <b>ENDIF</b>                                | End statement for IF code structures   |
| <b>ENDS</b>                                 | Command for end of switch case statement   |
| <b>GOSUB(value)</b>                         | Call a subroutine, value up to 999   |
| <b>GOTO(value)</b>                          | Jump program execution to a label, value up to 999   |
| <b>IF expression</b>                        | Conditional Test, expression can be multiple math operations   |
| <b>ITR(i, status_wrd#, bit#, s ,label#)</b> | Interrupt setup  |
| <b>ITRD</b>                                 | Global interrupt scanner disable   |
| <b>ITRE</b>                                 | Global interrupt scanner enable  |
| <b>LOOP</b>                                 | Loop command for while loops   |
| <b>PAUSE</b>                                | Pause program execution, used for interrupts   |
| <b>RESUME</b>                               | Resume program execution   |
| <b>RETURN</b>                               | Return from subroutine   |
| <b>RETURNI</b>                              | Return from interrupt  |
| <b>RUN</b>                                  | Start program execution  |
| <b>RUN?</b>                                 | Wait at this point for RUN command before program starts to execute                                      |
| <b>STACK</b>                                | Resets all GOSUB stack returns and Interrupts  |
| <b>SWITCH expression</b>                    | Switch case statement  |
| <b>TWAIT</b>                                | Wait for trajectory to complete, only used in program  |
| <b>TWAIT(gen#)</b>                          | Wait for trajectory generator (gen#) to complete it's move   |
| <b>TSWAIT</b>                               | Wait for synchronized trajectory to complete, down loaded program only * <b>COMBITRONIC</b> <sup>™</sup> |
| <b>WAIT=expression</b>                      | Set wait time in milliseconds  |
| <b>WHILE expression</b>                     | While loop format  |

## I/O Commands:

|                     |  |
|---------------------|--|
| <b>EIGN(#)</b>      | Assign a single I/O point as general use input                                     |
| <b>EIGN(W,0)</b>    | Assign all local I/O as general use inputs   |
| <b>EIGN(W,0,12)</b> | Assign inputs 2 and 3 as general use inputs at once (disabling over-travel limits) |
| <b>EIGN(W,0,m)</b>  | Assign a masked word-sized set of local I/O as general use inputs at once          |
| <b>EILN</b>         | Set port C (I/O-2) as negative over travel limit                                   |
| <b>EILP</b>         | Set port D (I/O-3) as positive over travel limit                                   |
| <b>EIRE</b>         | Set I/O 6 to capture external encoder's current value                              |
| <b>EIRI</b>         | Set I/O 6 to capture internal encoder's current value                              |
| <b>EISM(6)</b>      | Issue (G) when local input 6 goes low  |
| <b>EOBK(#)</b>      | Configure a given output to control an external brake                              |
| <b>IN(#)</b>        | x=IN( ), assign the state of a specific I/O to a variable (x in this case)         |
| <b>IN(W,0)</b>      | x=IN(W,0), assign the state of the first word of local I/O to the variable x       |
| <b>INA(A,#)</b>     | x=INA(A,#), raw analog reading: 10 bit resolution spanned over signed 16 bit range |

\* **COMBITRONIC**<sup>™</sup> These commands require Combitronic with -C or -DN product configuration option to execute.

# Command Set Overview

|                          |  |                        |  |
|--------------------------|--|------------------------|--|
| <b>INA(V,#)</b>          | x=INA(V,#), input voltage in millivolts of analog input value for a given I/O defined by # | <b>ADTS=expression</b> | Set sync accel/decel at once for a move<br>* <b>COMBITRONIC™</b>           |
| <b>INA(V1,#)</b>         | x=INA(V1,#), scaled 0-5 VDC reading in millivolts directly, 3456 would be 3.456 VDC        | <b>Ai(0)</b>           | Arm index rising edge of internal encoder                                  |
| <b>OC(#)</b>             | x=OC(#), individual output status, bit 1 if output is being driven                         | <b>Ai(1)</b>           | Arm index rising edge of external encoder                                  |
| <b>OC(W,#)</b>           | x=OC(W,#), block output status, bit 1 if output is being driven                            | <b>Aij(0)</b>          | Arm index rising edge then falling edge internal encoder                   |
| <b>OF(#)</b>             | x=OF(#), returns present fault state for I/O defined by #                                  | <b>Aij(1)</b>          | Arm index rising edge then falling edge external encoder                   |
| <b>OF(L,#)</b>           | x=OF(W,#), returns bit mask fault latched for I/O points                                   | <b>Aj(0)</b>           | Arm index falling edge of internal encoder                                 |
| <b>OF(W,#)</b>           | x=OF(W,#), returns bit mask of present faulted I/O points                                  | <b>Aj(1)</b>           | Arm index falling edge of external encoder                                 |
| <b>OR(value)</b>         | Reset output (turn off)  | <b>Aji(0)</b>          | Arm index falling edge then rising edge internal encoder                   |
| <b>OS(value)</b>         | Set output (turn on)   | <b>Aji(1)</b>          | Arm index falling edge then rising edge external encoder                   |
| <b>OUT(#)=expression</b> | if expression LSB = 1, then it's true(1), otherwise it's false (0)                         | <b>AMPS=expression</b> | Current limit value. 0-1023  |
| <hr/>                    |  | <b>AT=expression</b>   | Set the acceleration target for a move                                     |
| <b>Math Commands:</b>    |  | <b>ATS=expression</b>  | Set sync acceleration target for a move<br>* <b>COMBITRONIC™</b>           |
| -                        | Subtract   | <b>BREAK</b>           | Break out of while loop  |
| !                        | Bitwise exclusive OR   | <b>BRKENG</b>          | Manually Engage the brake  |
| !=                       | Not equal to   | <b>BRKRLS</b>          | Manually Release the brake   |
| %                        | Modulo (remainder) division  | <b>BRKSRV</b>          | Brake Servo, engage the brake when the drive is not active (default)       |
| &                        | Bitwise AND  | <b>BRKTRJ</b>          | Brake Trajectory   |
| *                        | Multiply   | <b>CTR(0)</b>          | Present value of internal encoder  |
| /                        | Divide   | <b>CTR(1)</b>          | Present value of external encoder  |
| ^                        | Power limited to 4th power and below, integers only  | <b>DEL=expression</b>  | Set maximum allowable derivative error limit                               |
|                          | Bitwise inclusive OR   | <b>DT=expression</b>   | Set the deceleration target for a move                                     |
| +                        | Add  | <b>DTS=expression</b>  | Set sync deceleration for a move * <b>COMBITRONIC™</b>                     |
| <                        | Less than  | <b>EL=expression</b>   | Set maximum allowable following error limit                                |
| <=                       | Less than or equal to  | <b>ENC1</b>            | Enable external encoder for servo  |
| ==                       | Equal to   | <b>ENC0</b>            | Enable internal encoder for servo  |
| >                        | Greater than   | <b>F</b>               | Set tuning values  |
| >=                       | Greater than or equal to   | <b>G</b>               | Go, initiates all buffered modes of operation                              |
| <b>ABS(value)</b>        | Absolute Value   | <b>G(gen#)</b>         | Go, initiate motion in trajectory generator (gen#)                         |
| <b>ACOS(value)</b>       | Arc Cosine   | <b>GS</b>              | Go synchronized, initiates linear interpolated moves * <b>COMBITRONIC™</b> |
| <b>ASIN(value)</b>       | Arc Sine   | <b>KA=expression</b>   | Feed forward gain  |
| <b>ATAN(value)</b>       | Arc Tangent  | <b>KD=expression</b>   | Derivative gain coefficient  |
| <b>COS(value)</b>        | Cosine   | <b>KG=expression</b>   | Gravity offset   |
| <b>FABS(value)</b>       | Floating point absolute value  | <b>KI=expression</b>   | PID integral gain  |
| <b>FSQRT(value)</b>      | Floating point square root   | <b>KL=expression</b>   | PID integral limit   |
| <b>RANDOM=expression</b> | Set the random seed value 0 to 2^31 - 1  | <b>KP=expression</b>   | PID proportional gain  |
| <b>RRANDOM</b>           | Report the next available random number in the range 0 to 2^31 - 1                         | <b>KS=expression</b>   | Differential sample rate   |
| <b>SIN(value)</b>        | Sine   | <b>KV=expression</b>   | Velocity feed forward gain   |
| <b>SQRT(value)</b>       | Square Root  | <b>MC</b>              | Initiate electronic camming  |
| <b>TAN(value)</b>        | Tangent  | <b>MC(2)</b>           | Set Trajectory Generator 2 to run in electronic camming                    |
| <b>TMR(x,t)</b>          | Sets timer x for t milliseconds  | <b>MDB</b>             | Enable TOB when in one of the 2 trapezoidal modes                          |
| <hr/>                    |  | <b>MDE</b>             | Set motor to enhanced trapezoidal mode commutation by using encoder        |
| <b>Motion Commands:</b>  |  | <b>MDS</b>             | Set motor to sine mode commutation   |
| <b>ADT=expression</b>    | Set the accel/decel at once for a move   |                        |  |

\* **COMBITRONIC™** These commands require Combitronic with -C or -DN product configuration option to execute.

# Command Set Overview

|  |  |                              |  |
|--|--|------------------------------|--|
| <b>MDT</b>   | Set motor to trapezoidal mode commutation using hall sensors (default mode)  | <b>SLN=<i>expression</i></b> | Set the negative software travel limit                               |
| <b>MFA(<i>value</i>)</b>                                 | Accel over <i>value</i> master distance. Default is zero (off)               | <b>SLP=<i>expression</i></b> | Set the positive software travel limit                               |
| <b>MFD(<i>value</i>)</b>                                 | Decel over <i>value</i> master distance. Default is zero (off)               | <b>T=<i>expression</i></b>   | Set the commanded torque while in MT mode                            |
| <b>MFDIV=<i>expression</i></b>                           | Assign Incoming counts Divisor   | <b>TH=<i>expression</i></b>  | Set maximum allowable thermal limit (degrees C)                      |
| <b>MFMUL=<i>expression</i></b>                           | Assign Incoming counts Multiplier  | <b>VT=<i>expression</i></b>  | Set the velocity target for a move                                   |
| <b>MFO</b>   | Initiate and zero counter, but do not follow                                 | <b>VTS=<i>expression</i></b> | Set synchronized velocity target for a move<br><i>* COMBITRONIC™</i> |
| <b>MFR</b>   | Select follow mode using quadrature encoder input.                           | <b>X</b>                     | Decelerate to a stop at present deceleration rate                    |
| <b>MFR(2)</b>  | Set Trajectory Generator 2 to run in Mode Follow Ratio (electronic Gearing)  | <b>X(<i>gen#</i>)</b>        | Decelerate to a stop , trajectory generate ( <i>gen#</i> )           |
| <b>MFSLEW(<i>value</i>)</b>                              | Stay at slew for <i>value</i> distance, then decel                           |                              |  |
| <b>MINV(0)</b>   | Default motor commutation direction  |                              |  |
| <b>MINV(1)</b>   | Invert commutation, shaft rotates opposite direction                         |                              |  |
| <b>MP</b>  | Initiate Position Mode   |                              |  |
| <b>MP(1)</b>   | Set Trajectory Generator 1 to run in Position Mode                           |                              |  |
| <b>MS0</b>   | Initiate and zero counter, but do not follow                                 |                              |  |
| <b>MSR</b>   | Calculate Mode Step Ratio and prepare to follow                              |                              |  |
| <b>MT</b>  | Initiate Torque Mode (Open Loop)   |                              |  |
| <b>MTB</b>   | Enable mode torque brake   |                              |  |
| <b>MV</b>  | Initiate Velocity Mode   |                              |  |
| <b>MV(1)</b>   | Set Trajectory Generator 1 to run in Velocity Mode                           |                              |  |
| <b>O=<i>expression</i></b>                               | Set origin, set present position to some value                               |                              |  |
| <b>O(<i>gen#</i>)=<i>expression</i></b>                  | Set origin for move <i>gen#</i> to some value                                |                              |  |
| <b>OFF</b>   | Turn the amplifier off   |                              |  |
| <b>OSH=<i>expression</i></b>                             | Origin shift of position counter on the fly                                  |                              |  |
| <b>OSH(<i>gen#</i>)=<i>expression</i></b>                | Shift origin for move <i>gen#</i> by some value                              |                              |  |
| <b>PID1</b>  | Set default PID update rate  |                              |  |
| <b>PID2</b>  | Set default PID/2 update rate  |                              |  |
| <b>PID4</b>  | Set default PID/4 update rate  |                              |  |
| <b>PID8</b>  | Set default PID/8 update rate  |                              |  |
| <b>PML=<i>expression</i></b>                             | Sets the position modulo limit wrap value                                    |                              |  |
| <b>PMT=<i>expression</i></b>                             | Set the position modulo target   |                              |  |
| <b>PRT=<i>expression</i></b>                             | Set the relative target position   |                              |  |
| <b>PRTS=(<i>dist1;axis1,dist2;axis2,dist3;axis3</i>)</b> | Set synchronized relative target position<br><i>* COMBITRONIC™</i>           |                              |  |
| <b>PRTSS=(<i>dis1;axis</i>)</b>                          | Set supplemental synchronized relative target position <i>* COMBITRONIC™</i> |                              |  |
| <b>PT=<i>expression</i></b>                              | Set the absolute target position   |                              |  |
| <b>PTS=(<i>dist1;axis1,dist2;axis2,dist3;axis3</i>)</b>  | Set synchronized absolute target position<br><i>* COMBITRONIC™</i>           |                              |  |
| <b>PTSS=(<i>dis1;axis</i>)</b>                           | Set supplemental synchronized absolute target position <i>* COMBITRONIC™</i> |                              |  |
| <b>S</b>   | Instantly stop motor   |                              |  |
| <b>S(<i>gen#</i>)</b>                                    | Instantly stop trajectory generator ( <i>gen#</i> )                          |                              |  |
| <b>SLD</b>   | Disable software travel limits   |                              |  |
| <b>SLE</b>   | Enable software travel limits  |                              |  |
| <b>SLM (0)</b>   | Make a soft limit only trigger the flag, but not cause a fault               |                              |  |
| <b>SLM (1)</b>   | Make s soft limit trigger the flag and cause a fault (default mode)          |                              |  |
|  |  | <b>CLK=<i>expression</i></b> | System Clock value in milliseconds                                   |
|  |  | <b>ERRC</b>                  | Get most recent command error code                                   |
|  |  | <b>ERRW</b>                  | Where/Who commanded most recent error                                |
|  |  | <b>FSA ( )</b>               | FSA(0,0) is default, sets all types of faults to result in MTB       |
|  |  | <b>RAC</b>                   | Report commanded acceleration  |
|  |  | <b>RAT</b>                   | Report target acceleration   |

## Status Commands:

|              |   |
|--------------|---|
| <b>Ba</b>    | Over current bit, status word 0, bit 4 status word 1, bit 3                               |
| <b>Be</b>    | Excessive position error, status word 0, bit 6  |
| <b>Bh</b>    | Excessive temperature occurred, status word 0, bit 5                                      |
| <b>Bi(0)</b> | Rising Edge Capture on Encoder 0 (internal), status word 1, bit 2                         |
| <b>Bi(1)</b> | Rising Edge Capture on Encoder 1 (external), status word 1, bit 6                         |
| <b>Bj(0)</b> | Falling Edge Capture on Encoder 0 (internal),   |
| <b>Bj(1)</b> | Falling Edge Capture on Encoder 1 (external), status word 1, bit 7                        |
| <b>Bk</b>    | Main program checksum error, program is corrupt and cannot run, status word 2, bit 15     |
| <b>Bl</b>    | Left (-) over travel limit, status word 0, bit 13   |
| <b>Bls</b>   | Left (-) over travel software limit occurred, status word 1, bit 13                       |
| <b>Bm</b>    | Left (-) over travel limit active, status word 0, bit 15                                  |
| <b>Bms</b>   | Left (-) over travel software limit active, status word 1, bit 15                         |
| <b>Bo</b>    | Motor is off, status word 0, bit 1  |
| <b>Bp</b>    | Right (+) over travel limit active, status word 0, bit 14                                 |
| <b>Bps</b>   | Right (+) over travel software limit active, status word 1, bit 14                        |
| <b>Br</b>    | Right (+) over travel limit, status word 0, bit 12  |
| <b>Brs</b>   | Right (+) over travel software limit occurred, status word 1, bit 12                      |
| <b>Bs</b>    | Command Syntax error note, status word 2, bit 14  |
| <b>Bt</b>    | Trajectory in progress, status word 0, bit 2  |
| <b>Bv</b>    | Velocity limit, status word 0, bit 7  |
| <b>Bw</b>    | Wrap around occurred, position wrapped through +/- 2 <sup>31</sup> , status word 3, bit 3 |
| <b>Bx(0)</b> | Hardware index input probe state for internal encoder, status word 1, bit 8               |
| <b>Bx(1)</b> | Hardware index input probe state for external encoder, status word 1, bit 9               |

*\* COMBITRONIC™* These commands require Combitronic with -C or -DN product configuration option to execute.

# Command Set Overview

|                   |   |                  |  |
|-------------------|---|------------------|--|
| <b>Ra</b>         | Report value of variable 'a'  | <b>RTMR(x)</b>   | Report timer x (present time left in milliseconds)       |
| <b>Rab[0]</b>     | Report value of ab[0]   | <b>RT</b>        | Report commanded torque                                  |
| <b>Raf[0]</b>     | Report floating point value of af[0]  | <b>RVC</b>       | Report commanded velocity                                |
| <b>Ral[0]</b>     | Report value of al[0]   | <b>RVT</b>       | Report target velocity                                   |
| <b>Raw[0]</b>     | Report value of aw[0]   | <b>RUIA</b>      | Reports current (Amps=UIA/100)                           |
| <b>REPTR</b>      | Reports EEPROM pointer value  | <b>RUJA</b>      | Reports bus voltage (Volts=UJA/10)                       |
| <b>RCKS</b>       | Report Checksum   | <b>RVA</b>       | Report actual velocity                                   |
| <b>RB(sw,b)</b>   | Report status bit, b, from status word, sw  | <b>RW(value)</b> | Report status word                                       |
| <b>RCLK</b>       | Report system clock in milliseconds   | <b>Z(sw,b)</b>   | Clears/zeros status word bits                            |
| <b>RCTR(0)</b>    | Report present value of internal encoder  | <b>Za</b>        | Reset over current bit                                   |
| <b>RCTR(1)</b>    | Report present value of external encoder  | <b>Ze</b>        | Reset position error bit                                 |
| <b>RDEA</b>       | Report actual derivative error  | <b>Zh</b>        | Reset over temperature bit                               |
| <b>RDEL</b>       | Report commanded derivative error limit   | <b>Zl</b>        | Reset left(-) historical limit bit                       |
| <b>RDT</b>        | Report target deceleration  | <b>Zls</b>       | Reset left(-) software historical limit bit              |
| <b>REA</b>        | Report actual following error   | <b>Zr</b>        | Reset right(+) historical limit bit                      |
| <b>REL</b>        | Report commanded following error limit  | <b>Zrs</b>       | Reset right(+) software historical limit bit             |
| <b>RI (0)</b>     | Report where the rising edge of the internal index was detected                               | <b>Zs</b>        | Reset syntax error bit                                   |
| <b>RI (1)</b>     | Report where the rising edge of the external index was detected                               | <b>ZS</b>        | Clear all errors, reset system latches to power up state |
| <b>RIN(#)</b>     | Report the state of a I/O   | <b>Zw</b>        | Reset wraparound bit                                     |
| <b>RIN(W,0)</b>   | Report the first word of local I/O  |                  |  |
| <b>RINA(A,#)</b>  | Reports analog input value for a given I/O defined by #                                       |                  |  |
| <b>RINA(V,#)</b>  | Reports voltage level (scaled from supply) of analog input value for a given I/O defined by # |                  |  |
| <b>RINA(V1,#)</b> | Reports voltage level (scaled 0-5 VDC) of analog input value for a given I/O defined by #     |                  |  |
| <b>RJ(0)</b>      | Report where the falling edge of the internal index was detected                              |                  |  |
| <b>RJ(1)</b>      | Report where the falling edge of the external index was detected                              |                  |  |
| <b>RMFDIV</b>     | Report Divisor  |                  |  |
| <b>RMFMUL</b>     | Report Multiplier   |                  |  |
| <b>RMODE</b>      | Report mode of operation  |                  |  |
| <b>RPA</b>        | Report present actual position  |                  |  |
| <b>RPC</b>        | Report present commanded position   |                  |  |
| <b>RPC(gen#)</b>  | Report commanded position for trajectory generator (gen#)                                     |                  |  |
| <b>RPMA</b>       | Report the current modulo counter   |                  |  |
| <b>RPML</b>       | Report position modulo limit  |                  |  |
| <b>RPMT</b>       | Report the most recent setting of PMT (position modulo target)                                |                  |  |
| <b>RPRA</b>       | Report actual relative position   |                  |  |
| <b>RPRC</b>       | Report commanded relative position  |                  |  |
| <b>RPRT</b>       | Report present relative target position   |                  |  |
| <b>RPT</b>        | Report present target position  |                  |  |
| <b>RRES</b>       | Report encoder resolution of motor  |                  |  |
| <b>RSLN</b>       | Report value of negative software limit   |                  |  |
| <b>RSLP</b>       | Report value of positive software limit   |                  |  |
| <b>RSP</b>        | Report sampling rate and firmware version   |                  |  |
| <b>RSP1</b>       | Report firmware revision date   |                  |  |
| <b>RTH</b>        | Report maximum allowable thermal limit  |                  |  |

---

**Variable Commands:**

|                               |   |
|-------------------------------|---|
| <b>a=expression</b>           | Variable, 32 bit signed integers, a-z, aa-zz, aaa-zzz, 78 total variables |
| <b>ab[x]=expression</b>       | Array variables, 8 bit byte arrays, x can be 0-203                        |
| <b>af[x]=expression</b>       | Floating point array variables, x can be 0-7                              |
| <b>al[x]=expression</b>       | Array variables, 32 bit long arrays, x can be 0-50                        |
| <b>aw[x]=expression</b>       | Array variables, 16 bit word arrays, x can be 0-101                       |
| <b>EPTR=expression</b>        | EEPROM pointer, non-volatile memory, use before VLD and VST commands      |
| <b>VLD(variable,quantity)</b> | Load values from EEPROM to variables starting at EPTR location            |
| <b>VST(variable,quantity)</b> | Store values to EEPROM from variables starting at EPTR location           |

---

**Other Commands:**

|                                      |  |
|--------------------------------------|--|
| <b>LOCKP</b>                         | Disable program (EEPROM) upload  |
| <b>UPLOAD</b>                        | Upload the program   |
| <b>OCHN(RS2,0,N,9600,1,8,C,1000)</b> | Default: (RS232,chan=0, no parity, 9600 baud,1 stopbit, 8 databits, command,1000 ms timeout) |
| <b>PRINT("Hello World",#13)</b>      | Print command to say "Hello World", see print section for more detailed examples             |
| <b>PRINT1("Hello World",#13)</b>     | Print command to say "Hello World" on channel 1, see print section for more detailed example |

**Note: See users guide for complete list of commands and full syntax.**  
**Many commands such as Cam mode and dual trajectory mode commands are not fully explained here.**